



Branch Hub Basic is a silent and compact computer appliance built on an ARM platform, using Linux for maximum security.

Branch Hub Basic is easy to set up and configure, using a GUI you access from a browser.

When using Qmatic equipment on a Qmatic 1745 network, the Branch Hub Basic has a built in 1745 socket, no special interface is required. Just connect the 1745 cable straight to Branch Hub Basic.

Features

- Supports Orchestra R4 and later
- Easy to set up and configure
- Built for 24/7 usage
- Low power and silent
- Small in size

With the Branch Hub Basic you can

- In a safe way, manage all the communication needs between the Qmatic equipment at a branch (such as printers, keypads and displays) and the Qmatic Orchestra central server

Used with	Qmatic Orchestra R4 and later	
Technical specifications	Dimensions: L x W x H	200 x 126 x 30 mm
	Weight	600 g
	External power supply	24 V, 2,5A
	Operating temperature	10-40°C
	Storage temperature	-20 – 80°C
	Operating humidity	15 – 75% R.H
	Storage humidity	10 – 90% R.H
Safety and other regulations	CE, RoHS2, WEEE	
The package contains	Branch Hub Basic	1
Available Power Cords	11040308	Power Cord EU
	11040309	Power Cord UK
	11040310	Power Cord USA
Article number	Branch Hub Basic	10214151

